

Auriel Integration Guide

| Manufacturer: | Integra, Onkyo | | | |
|-------------------------|---|--|--|--|
| Model Number(s): | Integra DTR40.4 / 50.4 / 70.4 / 20.3 / 30.3 / 40.3 / 50.3 / 70.3 / 80.3 / 40.1 / 50.1 / 70.1 / 80.1 Onkyo TX-NR515 / 616 / 717 / 818 / 1010 / 3010 / 5010 / 1007 / 3007 / 5007 | | | |
| Auriel Version: | 1.0 and above | | | |
| Comments: | FW 1.09 (1091-0999-0210-9105) | | | |
| Document Revision Date: | 7/31/15 | | | |

OVERVIEW AND SUPPORTED FEATURES

Integra/Onkyo AV Receivers include an Ethernet port which is connected to a Local Area Network (LAN), allowing the **Niles Auriel** system to provide full two-way communication; enabling reliable control and providing feedback to the **Niles Auriel** system when changes occur at the receiver.

INTEGRA/ONKYO RECEIVERS SUPPORT THE FOLLOWING FEATURES:

Basic Source and Volume Control: Select any available source and control volume with two-way feedback. Changes made at the receiver (turning the volume control, changing source) are immediately reflected in the **Niles Auriel** interface.

Satellite Radio Inputs: Integra receivers have inputs for Sirius Satellite Radio. These inputs are supported and use the standard **Niles Auriel** Satellite Tuner interfaces.

RDS: The RDS, or Radio Data System, is supported in the **Niles Auriel** interface where available.

INTEGRA RECEIVERS DO NOT SUPPORT THE FOLLOWING FEATURES:

Streaming Audio Sources: Digital music sources (USB, Ethernet, iPod etc.) are only available for source selection and volume control in **Niles Auriel**

Surround Mode Control: Is not support in Niles Auriel.

Tone Control (Integra 70.4/50.4/40.4 Onkyo TX-NR515/616/717/818/1010/3010/5010: These Integra/Onkyo models do not provide tone control (Bass/Treble).

Multiple AVR Zones: **Niles Auriel** supports the functionality of **ONE AVR Zone**. When using supported A/V Receivers with Zone 2 (or Zone 3) outputs, these additional zones will not function correctly through the **Auriel** system and are NOT supported.


Any feature not specifically noted as "supported" is not supported.

©2015 Core Brands, LLC. All rights reserved. Niles(R) is a registered trademark of Core Brands, LLC, a Nortek company. Features and specifications subject to change. All other trademarks are the property of their respective owners.

INSTALLATION OVERVIEW

- 1. During the rough-in phase, install the necessary speaker and video cabling for the theater installation.
- Also during the rough-in phase, run a Cat-5 wire from the location of the receiver back to the network switch location to provide the Ethernet connection needed to control the receiver. The Niles MRC-6430 should already be connected to the same LAN.
- 3. Install the speakers, display and other theater components.
- 4. Program the receiver according to the manufacturer's documentation.
- 5. If there are other Onkyo/Integra components in the system, (such as DVD player), those components can be connected to the A/V Receiver using the Integra RI connection. Beware that the RI link causes certain built-in behavior that cannot be disabled: when the Play command is issued to the DVD player, for example, the receiver automatically switches to the DVD source.
- 6. Test the receiver to ensure that the sources play correctly and that the audio and video operate as expected.
- 7. Configure the **Niles Auriel** system for the receiver and confirm communication between the receiver and the controller. See **Integral Onkyo Ethernet Configuration** details below.
- 8. Test the Auriel system by changing sources and volume to confirm that the correct source plays.

CONNECTION DIAGRAM: ETHERNET CONTROL



BILL OF MATERIALS

| # | Device | Manufacturer | Part # | Protocol | Connector Type | Notes |
|---|----------------------------|--------------|-----------|----------|--------------------------|---------------------------------|
| 1 | Cat-5 Cable | Installer | N/A | TCP/IP | RJ-45 Male to RJ-45 Male | Must terminate all 8 conductors |
| 2 | Network Assembly/Switch | Installer | N/A | TCP/IP | RJ-45 Female | |
| 3 | MRC-6430 Auriel Controller | Niles | 9901342 | TCP/IP | RJ-45 Female | |
| 4 | Integra A/V Receiver | Integra | See Notes | TCP/IP | RJ-45 Female | See Model Number(s) above |

INTEGRA/ONKYO ETHERNET CONFIGURATION

To enable reliable two-way control and feedback from the Onkyo/Integra AVR using Ethernet, **Network Control** must be enabled and a static IP address assigned.

- 1. Enter the **Setup** Menu either via the remote or the front panel.
- 2. Use the UP and DOWN arrows to navigate to and select 7. Hardware Setup
- 3. Use the **UP** and **DOWN** arrows to navigate to and select **6. Network**
- 4. Enter Settings as shown below, using the *Arrow Keys*:

| DHCP: Disable | Disable DHCP to prevent the unit receiving a variable dynamic IP address. | | |
|--|--|--|--|
| IP Address: (default) 192.168.0.50 | We recommended setting the Ethernet controlled AVR to 192.168.0.50, | | |
| Subnet Mask: 255.255.255.0 | (Typical Setting) | | |
| Gateway and DNS: (default) 192.168.0.1 | Set to Router LAN IP Address | | |
| Network Control: Enable | Enables external control. | | |
| Port: (default) 60128 | Port # required in software for control. This field is editable in both the AVR and Auriel software. The numbers in both must match to allow communication. | | |

5. Press *Return* to exit setup

COMMON MISTAKES

- 1. Incorrect firmware version. The Integra/Onkyo receiver was tested and developed on FW 1.09 and other firmware versions may affect the external control protocol.
 - To verify the Firmware version:
 - turn the unit ON
 - Press and hold the *Display* button and then press *ON* again.
 - The firmware version is displayed on the LCD screen.
- 2. No Satellite radio available for source/band selection on unit: Ensure that Satellite radio is enabled under **Setup>Hardware Setup>Tuner>Satellite Radio Mode**.
- 3. Configuring the unit to use DHCP will lead to eventual connectivity and control problems. It is recommended to set up the Integra AVR with a Static IP address for reliable control. Please see the **Integra Ethernet Configuration** information above for instructions.
- 4. Attempting to configure multiple AVR zones. Even when using supported models that have second and/or third zones, only ONE AVR zone will work correctly with **Auriel**.